

moxie

UNIQUE
WALLCOVERING

WIDTH 27" (68 cm)

ROLL LENGTH 4.5 linear yards (4 meters) sold in double rolls only

BACKING Paper

FACING Glitter

PATTERN MATCH Non-reverse hang, 25.25" (64 cm) vertical repeat, drop match

FIRE TEST ASTM E-84 Tunnel Test: Class A, flame spread 15, smoke developed 0 (test procedure is comparable to NFPA 255 and UL 723)

ADDITIONAL PRODUCT ATTRIBUTES

Cadmium and mercury free

Contains no heavy metals

Does not contain DEHP plasticizers

Free of PBDE's (Brominated Flame Retardants)

Water-based inks



WARRANTY Carefully examine your order for color, design, quantity or imperfections before cutting. Claims against wallcoverings will not be accepted after cutting and hanging. Manufacturer will replace all defective merchandise with new wallcoverings of equal value but will not be responsible for labor costs. Color changes (hot spots) or discoloration due to unneutralized plaster and improper wall preparations are not covered in this warranty.

Carefully examine this wallcovering for color, design, quantity and imperfections before installing. Warranty claims will be limited after cutting and hanging.

SURFACE PREPARATION Old wallcovering should be removed. Walls should be clean, dry and smooth. Prepare surface with a premixed, universal wallcovering primer.

- 1) Measuring from a corner of your starting wall, mark a vertical plumb line at a distance of 1" less than the paper width.
- 2) Cut your first strip of wallcovering 4" longer than the wall height you intend to cover.

3) FOR PRE-PASTED PAPER: Roll cut strip loosely with pattern side in, paste side out. Submerge rolled strip in warm water for 30 seconds to activate paste (or optionally, brush on a pre-paste activator).

FOR UNPASTED PAPER: Using a clear, light-to-medium weight, premixed adhesive, apply an even film of paste to the back of the paper, moving the paste brush or applicator from the center to the edge.

- 4) Fold moistened strip paste-to-paste and allow to set for 3 minutes.
- 5) Carry the wallcovering to the wall. Place one edge of your strip along the vertical plumb line and allow the remainder of the strip to go into and around the corner.
- 6) Smooth out bubbles using a smoothing brush. Trim top and bottom with a straight edge and razor knife. Wipe each strip clean with clean water and a sponge.
- 7) Using pattern match at baseboard and ceiling as a reference, determine the length of your next strip, allowing extra for trimming, then follow steps 2 and 3 above.
- 8) Slide the next strip into position with its edge butted against the edge of the preceding strip. Do not overlap seams. Gently roll butted seams with a seam roller. Be sure to match design of the adjacent strip at eye level. Repeat steps 6, 7 and 8.

Note: Reverse hang strips of wallcovering on random matched textures.

CLEANING OF WALLCOVERING Stains and paste on the surface should be removed as quickly as possible to eliminate any possible reaction between the staining agent and the wallcovering. Ordinary dirt and smudges can be removed with a mild soap and warm water. Clean from the bottom of the wall upward to protect the baseboard and to prevent streaking. Rinse thoroughly with clean water from the top down using a sponge. Blot wallcovering dry with a soft, lint-free towel. For more difficult stains, use of a stronger detergent is recommended. Try an inconspicuous spot first before attempting the entire wall. Always rinse the wall well after applying a detergent. Not recommended for cleaning are steel wool or powdered abrasive cleaners. Do not use active solvent-type cleaning preparations, such as nail polish remover, tar and bug removers, etc.